




Description

This is an Integrated sensor, it can be fixed at left or right side of bottom brackets .
The main features of this sensor is very thinner.
Automatic moving direction detect , so this sensor can check the moving direction while pedaling ,sending out signal when forward and stop sending when backwards.

Specification

• Model	: PAS12L /R
• Power	: 5V/2mA
• Signal	: Forward-12Pules Per Circle Reverse -None
• Material	: PC
• Wegiht)	:7.8g
• Axel Size	:15-15.8mm



Install Guide



Pack List

Sensor x1

Interface

Connector	: SM3 or Others
Red	: VCC
Black	: GND
White	: Signal

How to order

Items below must be declared clearly before order

- Model & Quantity
- Fix Position
(Left: PAS-12L Right : PAS-12R)
- Connector type
- Sequence of 3 pins
- Cable length
- Other special requirements