## Pedal Assist Sensor PAS-B12 L/R









### Description

This is an Integrated sensor, it can be fixed at left or right side of bottom brackets. Automatic moving direction detect, so this sensor can check the moving direction while pedaling, sending out signal when forward and stop sending when backwards.

Suzhou Minshine electronic co.,ltd

WWW.MINSHINE.CN

#### Specification


•	Model	: PAS-B12L/R
•	Power	: 5V/2mA
•	Signal	: Forward-12Pules Per Circle Reverse -None
•	Indicator	
		: Red Light
•	Material	: PC
•	Wegiht	:7.8g
•	Axel Size	:15-15.8mm



# Pedal Assist Sensor PAS-B12 L/R



### Appearance and size



#### Installation Instructions





